



Visit us at

www.energy-bots.com

www.flo senso.com

For Support contact us at
support@energy-bots.com



Toll Free No. : 1800 203 4902

INSTALLATION GUIDE

1. PACKAGE DETAILS
2. PRODUCT INFORMATION
3. INSTALLATION STEPS
4. IMPORTANT NOTES
5. SAFETY PRECAUTIONS & WARNINGS

1

1. PACKAGE DETAILS




Scan the QR code to download FloSenso App.




2


2. PRODUCT INFORMATION



Controller



Sensor



Sensor wire

3

3. INSTALLATION STEPS


Step 1:

Insert and tighten point A of the Sensor wire to the point A of the Controller



Step 2:


Install the sensor on the lid of the tank.



4


Step 3:

Connect the point B of the Sensor wire to the point B of the Sensor




Step 4:

In case you have a single switch or an MCB, ensure that you replace it with a 6 Amp (for FloSenso6AW) and 16 Amp (for FloSenso16AW) three pin socket and a switch. Please refer to your product packaging for the model number.



Step 5:

1. Plug the Controller into the switch board
2. Insert the plug of the pump into the Controller



Step 6:

Scan the QR code to open App Setup Guide. Follow the Steps to configure your FloSenso device



APP Setup Guide

5

4. IMPORTANT NOTES

- If you wish to use the FloSenso device without the mobile app, you can long press the Controller button for 10 seconds to switch ON/OFF the pump.
- If you are unable to troubleshoot or facing issues, raise a service ticket from the Menu >> raise ticket or Dashboard >> help icon.

5. SAFETY PRECAUTIONS & WARNINGS

- Controller is not weather proof. Keep it protected from rain, water and direct sun light.
- Sensor is splash and rain proof but do not submerge or drop the sensor in water. Place the Sensor away from the direct contact of water flowing into the tank.
- Screw the Sensor securely onto the lid. Tightly fasten the lid to the tank so that it is not loose.
- DO NOT cut the Sensor wire.
- Check the Max Load on the box. ensure that pump load is not more than the Max Load specified.
- Turn off the switch before plugging in and unplugging the pump Controller.
- Ensure that the Controller is plugged in securely into the socket in the switch board.
- Do not put finger inside the plug.
- Keep away from the reach of children.

6



Visit us at

www.energy-bots.com

www.flo senso.com

For Support contact us at

support@energy-bots.com


Toll Free No. : 1800 203 4902

इंस्टालेशन गाइड

1. पैकेज विवरण
2. प्रोडक्ट की जानकारी
3. इंस्टालेशन निर्देश
4. महत्वपूर्ण निर्देश
5. सुरक्षा सावधानियां और चेतावनी

1

1. पैकेज विवरण



FloSenso ऐप डाउनलोड करने के लिए इस QR Code को स्कैन करें।





GET IT ON Google Play

Download on the App Store

2

2. प्रोडक्ट की जानकारी




3

3. इंस्टालेशन निर्देश


स्टेप 1:

सेंसर के तार के सिरे A को कंट्रोलर के सिरे A में डालें और टाइट करें।



स्टेप 2:


सेंसर को टंकी के ढक्कन पर स्थापित करें।



4


स्टेप 3:

सेंसर के तार के सिरे B को सेंसर के सिरे B से जोड़ें।




स्टेप 4:

अगर आप सिंगल स्विच या MCB का इस्तेमाल कर रहे हैं तो इसे प्रोडक्ट मॉडल नंबर के अनुसार तीन पिन सॉकेट और स्विच से बदल दें। सुनिश्चित करें कि 6 AMP (FloSenso6AW के लिए) या 16 AMP (FloSenso16AW के लिए) तीन पिन सॉकेट और स्विच का प्रयोग हो रहा है।



स्टेप 5:

1. कंट्रोलर को स्विच बोर्ड में प्लग करें।
2. पंप के प्लग को कंट्रोलर में डालें।



स्टेप 6:

ऐप सेटअप गाइड खोलने के लिए QR कोड को स्कैन करें। अपने FloSenso उपकरण को सेटअप करने के लिए निर्देशों का पालन करें।



ऐप सेटअप गाइड

5

4. महत्वपूर्ण निर्देश

- यदि आप मोबाइल ऐप के बिना FloSenso का उपयोग करना चाहते हैं, तो पानी के पंप को चालू/बंद करने के लिए "कंट्रोलर बटन" 10 sec. के लिए दबा कर रखें।
- किसी समस्या के निवारण में असमर्थ हैं, तो ऐप के डैशबोर्ड या मेनू से सहायता के लिए अनुरोध करें। Menu >> Raise Ticket / Dashboard >> Help

5. सुरक्षा सावधानियां और चेतावनी

- कंट्रोलर मौसम रोधी नहीं है। इसे बारिश, पानी और सीधी धूप से बचा कर रखें।
- सेंसर स्प्लैश रोधी और बारिश रोधी है लेकिन इसे पानी में न डुबोएं या गिरने दें।
- सेंसर को टैंक में बहने वाले पानी के सीधे संपर्क से दूर रखें।
- सेंसर को ढक्कन पर सुरक्षित रूप से कस लें। टैंक के ढक्कन को कस कर बांधें ताकि वह ढीला न हो।
- सेंसर के तार को न काटें।
- पैकेजिंग पर Max Load की जाँच करें। सुनिश्चित करें कि पंप लोड निर्दिष्ट Max Load से अधिक न हो।
- पंप कंट्रोलर को प्लग इन और अनप्लग करने से पहले स्विच को बंद कर दें।
- सुनिश्चित करें कि नियंत्रक को स्विच बोर्ड में सॉकेट में सुरक्षित रूप से प्लग किया गया है।
- उंगली को प्लग के अंदर न डालें। गीले हाथों से पंप प्लग को प्लग या अनप्लग न करें।
- बच्चों की पहुँच से दूर रखें।

6